Project: Burj Khalifa
Document: Snagging report
Time Range: 2026-08-03 to 2026-08-10
Compiled by: SACO

Snagging Report 2026-08-03 to 2026-08-10

213 snagging cases in range

Error types

Black point	186
Flickering	20
Frozen	7

Fix types (qty)

Other	213

Daily logs

2026-08-03

Location	Error type	Fix types	Comments
B07-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B07-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B07-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B07-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-22	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-22	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-22	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-22	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C27-28	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C27-28	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C27-28	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

2026-08-04

Location	Error type	Fix types	Comments
C02-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C02-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C02-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C02-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C02-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C02-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-35	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-35	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-35	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-35	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B36-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B36-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B36-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B36-15	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B36-12	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B36-12	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B36-12	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B36-12	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B32-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B32-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B32-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B32-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C05-62	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C05-62	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C05-62	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C05-62	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C08-72	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
C08-72	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
C08-72	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C08-72	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C07-83	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-25	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-25	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-25	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-25	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B05-78	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B05-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B05-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B05-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B05-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B05-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C15-91	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C15-91	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C15-91	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C15-91	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C15-91	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C15-91	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

2026-08-05

Location	Error type	Fix types	Comments
C12-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C28-50	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C28-50	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C28-50	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C28-50	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-T23.2	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-T23.2	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-T23.2	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-T23.2	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-T23.2	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B04-T23.2	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B10-155.2	Black point	Other	Error type -> 17 - Black Point - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B26-49	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B26-49	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B26-49	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B26-49	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-54	Black point	Other	Error type -> 17 - Black Point - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-54	Black point	Other	Error type -> 17 - Black Point - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-54	Black point	Other	Error type -> 17 - Black Point - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-54	Black point	Other	Error type -> 17 - Black Point - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

2026-08-06

Location	Error type	Fix types	Comments
B22-52	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-52	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-51	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-50	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-16	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-16	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-16	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-16	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B04-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B04-18	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**

2026-08-07

Location	Error type	Fix types	Comments
B10-58	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B10-58	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B10-58	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B10-58	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B17-31	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B17-31	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B17-31	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B17-31	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B13-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B13-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B13-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B13-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B13-13	**Flickering**	**Other**	**Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B13-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B13-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B13-13	Flickering	Other	Error type -> 23 - Flickering - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B16-9	Frozen	Other	Error type -> 27 - Frozen - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B16-9	Frozen	Other	Error type -> 27 - Frozen - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B16-9	Frozen	Other	Error type -> 27 - Frozen - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B12-145	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B12-145	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B12-145	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B12-145	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-130	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-130	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-130	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B06-130	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B06-130	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-130	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

2026-08-08

Location	Error type	Fix types	Comments
B30-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B30-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B30-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B30-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B30-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B30-18	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-49	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-49	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-49	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B18-49	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B14-54	**Flickering**	**Other**	**Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B14-54	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B14-54	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B14-54	Flickering	Other	Error type -> 22 - Flickering - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

2026-08-09

Location	Error type	Fix types	Comments
B12-20	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B12-20	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-33	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-33	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C31-33	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C17-15	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
C29-42	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
C29-42	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C29-42	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C29-42	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C29-42	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C29-42	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C29-42	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C13-122	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C13-122	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C13-122	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C13-122	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-112	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-112	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-112	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
C12-112	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
C12-112	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C12-112	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C18-13	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B34-22	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B34-22	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B34-22	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B34-22	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B02-27	Frozen	Other	Error type -> 26 - Frozen - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B02-27	Frozen	Other	Error type -> 26 - Frozen - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B02-27	Frozen	Other	Error type -> 26 - Frozen - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
B02-27	**Frozen**	**Other**	**Error type -> 26 - Frozen - Loosing Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
B06-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B06-78	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C32-18	Black point	Other	Error type -> 19 - Black Point - Damaged Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C32-18	Black point	Other	Error type -> 19 - Black Point - Damaged Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C32-18	Black point	Other	Error type -> 19 - Black Point - Damaged Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C32-18	Black point	Other	Error type -> 19 - Black Point - Damaged Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C32-18	Black point	Other	Error type -> 19 - Black Point - Damaged Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C32-18	Black point	Other	Error type -> 19 - Black Point - Damaged Cable Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

2026-08-10

Location	Error type	Fix types	Comments
C16-69	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-69	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-69	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C16-69	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-57	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-57	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-57	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
B22-57	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C14-111	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C14-111	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C14-111	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C14-111	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE
C14-111	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE

Location	Error type	Fix types	Comments
C14-111	**Black point**	**Other**	**Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE**
C14-111	Black point	Other	Error type -> 18 - Black Point - Damaged V-stick Fix type -> CHECK FAILURE POINT. CHECK VSTICK AND CONNECTIONS. CONNECT/ REPLACE